

Foldable mini soccer goal

60x 45x24 cm

Before assembly and use, read the manual and follow its rules. Keep this manual for later reference.

IMPORTANT! BEFORE ASSEMBLING THE PRODUCT, READ THIS INSTRUCTIONS CAREFULLY AND

FOLLOW THE SIR RULES. KEEP THIS MANUAL FOR FUTURE REFERENCE.

Warning !!

- The product is not intended for children under 3 years of age. Danger of choking due to the presence of small elements.
- Product for private use only.
- The product may only be used by children under the supervision of an adult.
- The foot gate can only be placed on a soft floor such as grass.
- To avoid the goal tipping over, anchor all herrings firmly to the bottom, preferably with a rubber mallet.
- Always secure the gate to prevent it from tipping over.
- Do not set up the gate on the street or in other hazardous locations.
- Before use, make sure that all buttons between the individual metal bars are latched and that all connections are tightened securely.
- The condition of the gate should be checked before each use.
- The foot gate is weatherproof, but when the wind is strong, store it in a sheltered place or indoors.
- Do not climb on the frame or net of the goal net.
- The assembly and disassembly of the gate must always be carried out by an adult.
- Keep children away while folding and unfolding the product to prevent injury.
- The product should not be used if its components are damaged.
- After unpacking the product, throw away the plastic parts of the packaging, as they may be dangerous to children. Danger of suffocation.

Assembly

Editing can be done by one person, but the other person is helpful. Carry out the installation of the gate on an even, dry floor with sufficient free space. Remove all items from the packaging and remove all packaging materials. Check if any parts are missing and carry out the assembly in accordance with the instructions in the manual.

Maintenance and storage

You can clean the individual parts only with a damp cloth, do not use any detergents. All parts must be dry before packing. Then you can put it in a bag and store it in a cool and dry place.

Utilization

Individual parts should be disposed of in accordance with the existing assignments for a given material by throwing them into appropriate containers, and the rest to the household rubbish bin. In this way, by fulfilling the statutory obligation, we are simultaneously contributing to the protection of the environment.

Part List

① x 2pcs



② x 2pcs



③ x 6pcs

④ x 6pcs



⑤ x 1pc

⑥ x 1pc

Assembly step:

1）When you remove the carton, receive the soccer goal, it is foldable like below, lay it on the floor.



2）Next, firmly grasp the No. 1 tube upwards slowly, be sure the No. 3 tube remains on the ground, then put the No. 2 hook to fix the bolt on the No. 1 tube. Fasting the bolt of both sides.



3) Net assembly:





4)If you want to use it in the room, use suckers to fix the soccer goal with floor. Put the tube through the U shape of sucker, the plastic disc fix with floor.

If you want to use it in the garden, use anchor kit to fix.





Zestaw bramek piłkarskich Lopez

60x 45x24 cm

Zanim rozpoczniesz montaż, przeczytaj instrukcję. Zachowaj instrukcję przez cały okres używania zestawu bramek..

INFORMACJE OGÓLNE

Przed rozpoczęciem użytkowania produktu należy dokładnie zapoznać się z załączoną instrukcją. Osoby dorosłe powinny przekazać dzieciom zasady użytkowania produktu. Używać wyłącznie pod opieką osoby dorosłej.
Instrukcja jest integralną częścią produktu, przy przypadku przekazania produktu osobie trzeciej, należy przekazać również instrukcje. Instrukcje należy zachować przez cały okres użytkowania produktu.
Montaż powinien zostać przeprowadzony przez odpowiedzialną osobę dorosłą.
Produkt przeznaczony wyłącznie do użytku prywatnego.
Używać wyłącznie zgodnie z przeznaczeniem.

UŻYTKOWANIE

Bramkę ustawiać wyłącznie na równym podłożu.
Bramka powinna być przytwierdzona do podłoża także po zakończeniu użytkowania, aby uniknąć jej przewrócenia.
Unikać ekspozycji bramki na złe warunki pogodowe. W celu wydłużenia żywotności produktu poleca się przechowywanie w suchym pomieszczeniu (gdy nie jest używana).
Przetarcia i zadrapania mogą skutkować zdarciem powłoki antykorozyjnej. Montaż oraz demontaż powinien zostać wykonywany ostrożnie. W wypadku pojawienia się rdzy na uszkodzonej powierzchni zaleca się jak najszybsze jej usunięcie oraz zabezpieczenie przeznaczonymi do tego środkami.
Należy regularnie sprawdzać stan łączeń rurek i profili.
Czyścić jedynie delikatnymi środkami czystości.
Dzieci mogą używać produktu wyłącznie pod opieką odpowiedzialnej osoby dorosłej.
Nie należy wspinać, ani wieszać się na poprzeczce ani rurkach, grozi to zniszczeniem produktu oraz stwarza zagrożenie dla użytkownika.

OSTRZEŻENIE!

Produkt nieodpowiedni dla dzieci poniżej 3 roku życia, zawiera linki oraz małe elementy, istnieje ryzyko uduszenia lub połknięcia!
Opakowanie nie jest zabawką, trzymać z daleka od dzieci, istnieje ryzyko uduszenia!

Lista części

① x 2pcs



② x 2pcs



③ x 6pcs

④ x 6pcs



⑤ x 1pc

⑥ x 1pc

Kroki montażu:

1）Kiedy wyciągniesz bramkę z kartonu, połóż ją na płaskim podłożu tak, jak to przedstawiono na rysunku:



2）Podnieść część nr (zaznaczoną na rys. 1), jednocześnie przytrzymaj część 3 tak, żeby dotykała podłoża. Następnie umieść hak (nr2) w miejscu, który pokazano na rysunku.



3) Montaż siatki – postępuj według kroków na rysunku:





4) Możesz skorzystać z przyssawek, jeżeli chcesz przytwierdzić bramki do płaskiej powierzchni typu parkiet. Pamiętaj, że podłoże musi być odpowiednie, ponieważ nie na każdym przyssawki będą działać. Na powierzchni trawiastej użyj śledzi do przymocowania bramek.